# **CAPEXI**® Exhaust System

### Installation Sheet

### □Application Vehicle

2001∼	Year	HONDA Civic Coupe	Vehicle Name
D17A2	Engine Type	nbe	
116-KH21	Apex Product Code	EU1	Vehicle Code

#### □Parts List

No.	Part Name	Size	Qty	Qty No	Part Name	Size	Qty
$\Theta$	Apex Front Muffler   Vehicle Specific	Vehicle Specific	1	6	Bolt	$M10 \times P1.25 \times L40$	4
0	Apex Middle Muffler Vehicle Specific	Vehicle Specific	1	② Nut	Nut	M10×P1.25	7
3	Apex Main Muffler	Vehicle Specific	1	8	8 Washer	M10	11
4	Gasket	$\phi$ 61.5 × PCD86	1	9	Apex Instruction Manual		1
<b>⑤</b>	Gasket	$\phi$ 61.5 × P90	2	1			

## □Apex Exhaust System Installation Procedure

1.Install the muffler according to the diagram below and hand tighten the nuts and bolts in place.

XThe diagram only shows partial usage of the nuts and bolts. Please use all of them.

2 Take note of piping clearance, gasket positioning, tip position, chassis clearance and tighten

the nuts and bolts into position. Start from the catalytic converter side and work your way back

# Torque Specification M10 43~55N·m 4.4~5.6 kgf·m 31.8~40.5lb·ft

3.Be sure to confirm tail pipe positioning so that it does not touch the rear bumper. If the positioning unnecessary sound and may melt the bumper.

CAUTION is off,loosen the nuts and bolts and adjust accordingly. Failure to provide adequate clearance may cause

Be sure to check clearances between brake components, fuel line, and drive train components.

### ☐ Checkpoints after Installation

After installation, move the exhaust system side to the side by hand to confirm clearances

2. Rev the engine to 2500rpm to check for any exhaust leaks.

3. Test drive the vehicle and check for exhaust leaks or unusual sounds.

4.If anything usual occurs in steps  $1\sim3$ , reinstall the muffler system.

5.Retighten all of the nuts and bolts after 200 $\sim$ 300km.



