

Installation Sheet

□Application Vehicle

1992~1995	Year	Honda Civic HB SI
D16Z6	Engine Type	<u>s</u>
Z6	Гуре	
162-KH02	Apex Product Code	EH3

□Parts List

	4 Gasket	3 Apex Main Muffler	② Apex Middle Muf	① Apex Front Muffler	No. Part Name
$P90 \times \phi 61.5$	PCD86 × ϕ 61.5	r Vehicle Specific	Apex Middle Muffler Vehicle Specific	er Vehicle Specific	Size
2	1	_	1	1	Qty
	9	8	7	6	Qty No.
	Apex Instruction Manual	® Washer	Nut	Bolt	Part Name
		M10	M10×P1.25	$M10 \times P1.25 \times L40$	Size
	1	11	7	4	Qty

□Apex Exhaust System Installation Procedure

The diagram only shows partial usage of the nuts and bolts. Please use all of them. 1.Install the muffler according to the diagram below and hand tighten the nuts and bolts in place

2. Take note of piping clearance, gasket positioning, tip position, chassis clearance and tighten the nuts and bolts into position. Start from the catalytic converter side and work your way back

Torque Specification

M10 $43\sim55$ N m $4.4\sim5.6$ kgf m $31.8\sim40.5$ lb ft 5~ 7N m 0.5~0.6 kgf m 3.6~ 4.4lb ft

3.Be sure to confirm tail pipe positioning so that it does not touch the rear bumper. If the positioning unnecessary sound and may melt the bumper.

CAUTION is off, loosen the nuts and bolts and adjust accordingly. Failure to provide adequate clearance may cause

Be sure to check clearances between brake components, fuel line, and drive train components.

□Checkpoints after Installation

1.After installation, move the exhaust system side to side by hand to confirm clearances

2.Rev the engine to 2500rpm to check for any exhaust leaks.

4.If anything usual occurs in steps $1\sim3$, reinstall the muffler system. 5.Retighten all of the nuts and bolts after 100~200m.

3. Test drive the vehicle and check for exhaust leaks or unusual sounds.

