



Silver Bullet

Throttle Body Spacer

PN 46-38008

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Model	Year	Engine
4Runner	2010	V6-4.0L

1. Remove the engine cover to expose the throttle body.
2. Loosen the two hose clamps securing the intake tube to the throttle body and intake housing.
3. Remove the two small hoses that connect to the rear of the intake tube. Disconnect the wire harness from the Mass Air Flow Sensor (MAF Sensor).
4. Remove the mounting bolt securing the intake tube to the bracket.
5. Remove the intake tube from the vehicle.
6. Remove the four (4) bolts securing the throttle body to the intake manifold.
7. Install the aFe Silver Bullet throttle body spacer (AIR IN engraving side faces the throttle body). The supplied gasket is to be placed between the throttle body and the spacer. Using the supplied washers and longer bolts secure the throttle body to intake manifold and tighten to 10 Nm (89 lb/in).
8. Re-install the intake tube and secure it to the bracket using the stock bolt.
9. Re-connect all vent hoses and the MAF wire harness and tighten all clamps.
10. Re-install the engine cover and your installation is now complete. Enjoy.



Parts List

- 1 aFe Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 70mm bolts
- 4 6mm lock washers

advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com